

**Warsaw University
of Technology**



**Faculty of Power and
Aeronautical Engineering**

WARSAW UNIVERSITY OF TECHNOLOGY

Institute of Aeronautics and Applied Mechanics

Finite element method 2 (FEM2)

Introduction


10.2021

The finite element method (FEM) is an approximate method which can be used as a numerical procedure to solve physical problems including:

- solid body mechanics,
- heat transfer,
- fluid flow,
- electromagnetism,
- coupled field problems
- ...

FEM was developed in 1950s to solve problems for the civil and aeronautical industry. The method become the most powerful analysis tool, mainly due to the development of computers.


Modelling



Errors

total error = modelling error + discretization error + numerical error

modelling error ≈ discretization error ≈ numerical error → min



Modelling error


Available information about the real object:

- material data
- geometry
- work conditions

Simplifying assumptions

- dimensionality
- material model
- nonlinearities
- type of load

Example. Wooden board loaded by gravity.




Discretization error

Discretization



- type (mapped, free, sweep)
- density

Finite element




- shape functions
- integration scheme



Example. Plate with notches



Stress components at the notch tip versus element size d (numerical results)



--- EXACT SOLUTION OF A MATHEMATICAL MODEL

Numerical error

- solver
- condition number

$$cond([K]) = \|K\| \cdot \|K\|^{-1}$$

- rounding (number of significant digits)

Approximately, if the condition number $cond([K]) = 10^k$, then up to k digits can be lost during solution of the system of linear equations.


$$r \geq p - \log_{10}(cond([K]))$$

p – number of significant digits in the computer representation of numbers


r – number of significant digits of the result

In FE models the value of $cond([K])$ can reach 10^8

FE modeling – basic steps




Example. DOF solution $u(x,y)$ for 2D problem. FE model with 4-node quadrilaterals




$$\{u\} = [N]\{q\}_e$$

2×1 2×8 8×1




$u_e(x, y)$ – displacement function in a finite element along x axis



$$u_e = [N_1 \ 0 \ N_2 \ 0 \ N_3 \ 0 \ N_4 \ 0] \begin{Bmatrix} q_1 \\ q_2 \\ q_3 \\ q_4 \\ q_5 \\ q_6 \\ q_7 \\ q_8 \end{Bmatrix}_e$$

Example. Stress component $\sigma_x(x, y)$ for 2D problem. FE model with 4-node quadrilateral elements



For $k = 4$:

$$\sigma_{x_i}^{AVE} = \frac{\sigma_{x_1}(x_i, y_i) + \sigma_{x_2}(x_i, y_i) + \sigma_{x_3}(x_i, y_i) + \sigma_{x_4}(x_i, y_i)}{4}$$